

Garmin Automotive GPS Units



All StreetPilot units are "Unknown" as their specifications are not clear whether they will support supplemental maps.



(Includes LM and LMT models).

Nuvi 30, 40, 42, 44, 50, 52, 54, 55, 56, 57, 58, 60, 65, 66, 67, 68
Nuvi 200, 205, 250, 255, 260, 265, 270, 275, 285, 295
Nuvi 350, 360, 370
Nuvi 465
Nuvi 500, 550
Nuvi 600, 610, 650, 660, 670, 680

Nuvi 750, 755, 760, 765, 770, 775, 780, 785
Nuvi 850, 855, 880, 885
Nuvi 1100
Nuvi 1200, 1250, 1260
Nuvi 1300, 1350, 1370, 1390
Nuvi 1450, 1490
Nuvi 1690
Nuvi 2240, 2250
Nuvi 2310, 2340, 2350, 2360, 2370
Nuvi 2440, 2450, 2455, 2460, 2475, 2495
Nuvi 2555, 2557, 2589, 2595, 2597, 2599
Nuvi 2639, 2689
Nuvi 2757, 2789, 2797
Nuvi 3450, 3490
Nuvi 3750, 3760, 3790

Garmin Drive 50, 51, 52, 60, 61 **Can not use SD card to load map. MUST USE DOWNLOAD**
Garmin Drive 6 **Can not use SD card to load map. MUST USE DOWNLOAD**
Garmin DriveSmart 55, 61, 65 **Can not use SD card to load map. MUST USE DOWNLOAD**

Garmin Motorcycle GPS Units



(Includes LM and LMT models).

Zumo 220
Zumo 350, 390, 395, 396
Zumo 660, 665
Zumo 550, 590, 595
Zumo XT




BMW Motorrad Navigator IV

Garmin Off Road Units



Overlander
Tread

Garmin Outdoor (Handheld) GPS Units



Dakota 10, 20



- Oregon 200
- Oregon 300
- Oregon 400, 450
- Oregon 550
- Oregon 600, 650 (includes (T)opo models)
- Oregon 700, 750 (includes (T)opo models)



Colorado 300
Colorado 400
Colorado 400c, 400i, 400t



Montana 600, 610, 650, 680 (includes (T)opo models)
Montana 700, 700i, 750, 750i



Monterra



etrex "yellow" - *** Can't add maps



etrex Camo - *** Can't add maps



- etrex Legend - Serial Interface Required
- etrex Legend C
- etrex Legend Cx - No internal memory, must use microSD
- etrex Legend H
- etrex Legend HCx - No internal memory, must use microSD



- etrex Venture - *** **Can't add maps**
- etrex Venture Cx - No internal memory, must use microSD
- etrex Venture HC



etrex Vista HCx - No internal memory, must use microSD
etrex Vista
etrex Vista C
etrex Vista Cx
etrex Vista H



etrex Summit - *** Can't add maps
etrex Summit HC



etrex H - *** Can't add maps



etrex 10 - *** Can't add maps
etrex 20
etrex 30



GPSMAP 60
GPSMAP 60CS, 60CSx, 60Cx - No internal memory, must use microSD
GPSMAP 62, 62s, 62sc, 62st, 62stc
GPSMAP 64, 64s, 64st



GPSMAP 76, 76S - Serial interface
GPSMAP 76CSx, 76Cx - No internal memory, must use microSD
GPSMAP 76C, CS



GPSMAP 78, 78sc



GPSMAP 276Cx



GPS II - Unknown
GPS III - Unknown



GPS 60 - *** Can't add maps
GPS 72 - *** Can't add maps
GPS 76 - *** Can't add maps





Rino 110 - *** Can't add maps

Rino 120

Rino 130

Rino 520

Rino 520HCx - No internal memory, must use microSD

Rino 530

Rino 530HCx - No internal memory, must use microSD



Rino 610, 650, 655t



eMap

Garmin Boating (On the Water) GPS Units



GPSMAP 276C
GPSMAP 376C



GPSMAP 620, 640

The larger chartplotter GPSMAP series and the echoMAP chartplotters that are not compatible with the Garmin City Navigator map will NOT run our maps. There are many other GPSMAP marine units for "On the Water" that we have not researched.


Garmin Cycling GPS Units



- Edge 200 - Can't add maps
- Edge 500 - Can't add maps
- Edge 510 - Can't add maps



Edge 800
Edge 810
Edge 1000



Edge Touring
Edge Touring Plus